


Adjust sliding cylinder carousel in/out



If you think the carousel moves too fast or slow, please adjust the forward knob J, the buffer knob L and the backward knob M to reach your required speed.