

## Spindle encoder mounts at the shaft of spindle motor

New Encoder



Install bracket to encoder & 2 set screws



Remove 4 screws. Using clean paper to cover the holes to prevent the screws drop in the motor.



Install encoder at the shaft of motor and tighten 2 set screws to the shaft and 2 screws to hold the bracket of encoder.



Remove the cover of DB9.

