

How to Install PLC

System Admin → Password 520 → System Setting Manager → Import
→ select USBDisk → select cnc.lad → OK → Restart machine